



# Bosch Wiper Blades

Zero-compromise vision, at all times.

Your Dealer's Address

243 | 2011 | WBI | 4W | L

**Bosch Limited, Automotive Aftermarket**, P.B. No. 3000, Hosur Road, Adugodi, Bengaluru - 560 030. Ph: (080) 2299 9228. Fax: (080) 2299 9796. [www.boschindia.com](http://www.boschindia.com)

**Sales Offices:** **Ahmedabad:** Ph.: (079) 6614 2200 - 08. **Bengaluru:** Ph.: (080) 2213 2081/ 2227 7653/ 2227 9672. **Bhubaneswar:** Ph.: (0651) 223 2801. **Chandigarh:** Ph.: (0172) 263 8207. **Chennai:** Ph.: (044) 2815 5815/ 2815 3916. **Delhi:** Ph.: (011) 2334 8260/ 61. **Ernakulam:** Ph.: (0484) 280 5601. **Ghaziabad:** Ph.: (011) 4316 6145. **Guwahati:** Ph.: (0361) 213 1647/ 648. **Indore:** Ph.: (0731) 425 5010. **Jaipur:** Ph.: (0141) 238 7048. **Kolkata:** Ph.: (033) 2217 4221/ 2226 5360/ 2217 6739. **Lucknow:** Ph.: (0522) 326 4409/ 320 8474/ 75. **Madurai:** Ph.: (044) 2815 5815/ 2815 3916. **Mumbai:** Ph.: (022) 24943 2071. **Nagpur:** Ph.: (0712) 268 1738. **Panchkula:** Ph.: (0172) 458 7735. **Patna:** Ph.: (0612) 645 0685. **Pune:** Ph.: (020) 6725 4769. **Punjab:** Ph.: (0172) 458 7708. **Raipur:** Ph.: (0771) 402 6333/ 444. **Rajkot:** Ph.: (0281) 246 1571. **Ranchi:** Ph.: (0651) 236 1152. **Secunderabad:** Ph.: (040) 2799 0366. **Vijayawada:** Ph.: (040) 2799 0266/ 0308.



# Bosch Wiper Blades

## Presenting Bosch Wiper Blades - Ensuring total visibility

For the first time in India, Bosch Wiper Blades come with **Graphite Coating** to ensure smoother wiping and, are fitted with a pre-mounted Quick-Clip Adaptor for ease and quick installation.

- ▶ World renowned Bosch technology
- ▶ Graphite Coating on wiper ensures smooth wiping
- ▶ Bosch Tropical Wiper Blades with special rubber formulation best suited for Indian climate
- ▶ Double micro wiping edge for clear vision day and night
- ▶ Special metal construction eliminates vibration during high-speed driving
- ▶ Flip over action of wiper lip ensures no chattering or squeaking on the windshield
- ▶ Large coverage for Indian market



### Application Chart

Application	Date	Length (mm, inch)	Part No.
<b>Chevrolet</b>			
Aveo	03.06 ->	550 / 400, 22" / 16"	3 397 010 055
Optra	06.03 ->	530 / 480, 21" / 19"	3 397 010 053
Tavera	05.04 ->	550 / 400, 22" / 16"	3 397 010 055
Tavera (Rear)*	05.04 ->	340 / 340, 13.5" / 13.5"	3 397 004 875
<b>Daewoo</b>			
Cielo	01.95 - 11.01	450 / 450, 18" / 18"	3 397 005 293
Matiz	11.98 - 07.02	500 / 420, 20" / 17"	3 397 010 050
Matiz (Rear)*	11.98 - 07.02	340 / 340, 13.5" / 13.5"	3 397 004 875
<b>Fiat</b>			
Palio	07.01 ->	600 / 400, 24" / 16"	3 397 010 057
Siena	01.02 - 03.04	600 / 400, 24" / 16"	3 397 010 057
Uno	01.98 - 03.04	480 / 480, 19" / 19"	3 397 005 294
Uno (Rear)*	01.98 - 03.04	300, 12"	3 397 005 290
<b>Force Motors</b>			
Gama	05.00 ->	400, 16"	3 397 005 291
Trax	05.95 ->	400 / 400, 16" / 16"	3 397 005 291
<b>Ford</b>			
Endeavour	09.03 ->	450 / 450, 18" / 18"	3 397 005 293
Escort	12.97 ->	500 / 500, 20" / 20"	3 397 005 295
Fiesta	10.05 ->	550 / 400, 22" / 16"	3 397 010 055
Fusion	11.04 ->	550 / 400, 22" / 16"	3 397 010 055
Ikon	01.00 ->	480 / 480, 19" / 19"	3 397 010 055
<b>H M</b>			
Ambassador Nova (Old)	01.90 - 05.99	300, 12"	3 397 005 290
Ambassador Nova (New)	05.99 - 05.04	340 / 340, 13.5" / 13.5"	3 397 004 875
Contessa	03.93 ->	450 / 450, 18" / 18"	3 397 005 293

Application	Date	Length (mm, inch)	Part No.
<b>Honda</b>			
Accord	07.01 ->	600 / 400, 24" / 16"	3 397 010 057
City	12.97 - 09.03	500 / 450, 20" / 18"	3 397 010 051
City	10.03 ->	550 / 350, 22" / 14"	3 397 010 060
CRV	08.04 ->	530 / 480, 21" / 19"	3 397 010 053
<b>Hyundai</b>			
Accent	11.99 ->	500 / 450, 20" / 18"	3 397 010 051
Elantra	06.04 ->	500 / 450, 20" / 18"	3 397 010 051
Getz	09.04 ->	550 / 350, 22" / 14"	3 397 010 060
Getz (Rear)*	09.04 ->	340 / 340, 13.5" / 13.5"	3 397 004 875
Santro	09.98 ->	500 / 420, 20" / 17"	3 397 010 050
Santro (Rear)*	09.98 ->	340 / 340, 13.5" / 13.5"	3 397 004 875
Sonata	07.01 ->	530 / 480, 21" / 19"	3 397 010 053
Verna	05.12 ->	550 / 400, 22" / 16"	3 397 010 055
<b>Mahindra</b>			
Armada	01.93 - 10.00	300, 12"	3 397 005 290
Bolero	05.00 ->	400 / 400, 16" / 16"	3 397 005 291
Camper	06.03 ->	400, 16"	3 397 005 291
Champion	06.01 ->	400, 16"	3 397 005 291
Hardtop	03.96 ->	300, 12"	3 397 005 290
Invader	06.03 ->	400, 16"	3 397 005 291
Logan	02.07 ->	500, 20"	3 397 005 295
Marshal	11.00 ->	300, 12"	3 397 005 290
Maxx	05.00 ->	300, 12"	3 397 005 290
Pickup	01.01-11.03	300, 12"	3 397 005 290
Scorpio	06.02 ->	480 / 480, 19" / 19"	3 397 005 294
Scorpio (Rear)*	06.02 ->	340 / 340, 13.5" / 13.5"	3 397 004 875
Utility	01.00 -11.00	300, 12"	3 397 005 290

### Application Chart

Application	Date	Length (mm, inch)	Part No.
<b>Mahindra</b>			
Voyager	02.98 ->	400, 16"	3 397 005 291
<b>Maruti</b>			
800	12.83 ->	420 / 420, 17" / 17"	3 397 005 292
800 (Rear)*	12.83 ->	300, 12"	3 397 005 290
Alto	09.00 ->	450 / 400, 18" / 16"	3 397 010 054
Alto (Rear)*	09.00 ->	300, 12"	3 397 005 290
Baleno	11.99 ->	500 / 450, 20" / 18"	3 397 010 051
Baleno (Rear)*	11.99 ->	340 / 340, 13.5" / 13.5"	3 397 004 875
Esteem	11.94 ->	500 / 450, 20" / 18"	3 397 010 051
Gypsy	11.96 ->	300, 12"	3 397 005 290
Omni	11.84 ->	300, 12"	3 397 005 290
Swift	05.05 ->	530 / 480, 21" / 19"	3 397 010 053
Versa	10.01 ->	400 / 400, 16" / 16"	3 397 005 291
WagonR	01.00 ->	450 / 400, 18" / 16"	3 397 010 054
WagonR (Rear)*	01.00 ->	340 / 340, 13.5" / 13.5"	3 397 004 875
Zen	10.93 ->	500 / 420, 20" / 17"	3 397 010 050
Zen (Rear)*	10.93 ->	300, 12"	3 397 005 290
<b>Mercedes Benz</b>			
M - Class	12.02 ->	500 / 500, 20" / 20"	3 397 005 295
<b>Mitsubishi</b>			
Cedia	01.06 ->	530 / 480, 21" / 19"	3 397 010 053
Lancer	01.98 ->	530 / 480, 21" / 19"	3 397 010 053
<b>Opel</b>			
Astra	01.96 ->	450 / 450, 18" / 18"	3 397 005 293
Corsa	01.00 ->	450 / 450, 18" / 18"	3 397 005 293
Swing	01.01 ->	450 / 450, 18" / 18"	3 397 005 293
<b>Premier</b>			
Padmini	10.86 - 12.00	300, 12"	3 397 005 290

Application	Date	Length (mm, inch)	Part No.
<b>Premier</b>			
Road Star	10.06 ->	400, 16"	3 397 005 291
Sigma	10.06 ->	400, 16"	3 397 005 291
<b>Skoda</b>			
Octavia	09.96 - 01.05	530 / 480, 21" / 19"	3 397 010 053
<b>Tata</b>			
ACE	05.05 ->	500 / 420, 20" / 17"	3 397 010 050
207 DI	05.02 ->	500, 20"	3 397 005 295
Estate	11.92 ->	480 / 480, 19" / 19"	3 397 005 294
Indica	02.99 - 08.01	500 / 500, 20" / 20"	3 397 005 295
Indica	09.01 ->	600 / 400, 24" / 16"	3 397 010 057
Indica (Rear)*	02.99 ->	300, 12"	3 397 005 290
Indigo	12.02 ->	600 / 400, 24" / 16"	3 397 010 057
Mobile	06.99 - 03.02	500, 20"	3 397 005 295
Safari	02.98 ->	550 / 550, 22" / 22"	3 397 005 296
Safari (Rear)*	02.98 ->	340 / 340, 13.5" / 13.5"	3 397 004 875
207 Safari	05.02->	600 / 400, 24" / 16"	3 397 010 057
Safari -TD	02.98 ->	500, 20"	3 397 005 295
Sierra	11.89 ->	480 / 480, 19" / 19"	3 397 005 294
Sumo	11.94 ->	480 / 480, 19" / 19"	3 397 005 294
<b>Toyota</b>			
Camry	10.02 ->	600 / 400, 24" / 16"	3 397 010 057
Corolla	02.03 ->	600 / 400, 24" / 16"	3 397 010 057
Innova	01.05 ->	600 / 400, 24" / 16"	3 397 010 057
Innova (Rear)*	01.05 ->	300, 12"	3 397 005 290
Qualis / Qualis (Rear)*	02.00 - 12.04	400 / 400, 16" / 16"	3 397 005 291

\*Only one required for rear application

**Note:** For models older than 1998, please use S/S adaptor (Screw Type Fitment) - 3 392 390 400 supplied separately.

